


38 805 000 **SKATE COSMOPOLITAN SET FRESH FLUSH PLATE**



SPARE PARTS

- 1: Frame (Spare part-nr. 42358000)
- 1.1: Screw (Spare part-nr. 6636200M)
- 2: Top plate with push button (Spare part-nr. 42371000)
- 3: Fixing set (Spare part-nr. 4308500M)*

* Optional accessories