

Pure Freude
an Wasser



48 361 000 **WC PUSH BUTTON**

No exploded view is available for this spare part list.

SPARE PARTS

1: pushbutton (Spare part-nr. 14077000)